



TELINGA Microphones,

Parabolic microphones & other equipment for Wildlife Sound Recording.

CARE:

All models.

The dish:

Keep the dish rolled up only when necessary. Clean with soap only. The dish can be polished with car wax.

Do not use mosquito spray on the dish.

The handle:

On dusty roads, keep in a plastic bag. Wipe off now and then with a piece of cloth. Silicon spray prolongs finish of handle and life of cables.

When the microphone is not going to be used for weeks, - remove the handle from the grey plastic tube.

Use a drop of household oil sometimes, on screws and connection plug.

The microphones:

On dusty roads, keep in a plastic bag. Wipe off now and then with a piece of cloth.